

Fixing Instructions

Quelfire QWW CE Marked Intuwraps are life saving products designed to prevent the spread of fire where plastic pipes penetrate fire compartment floors. It is therefore essential that they are fitted in a responsible and workmanlike manner.

The Quelfire QWW CE Marked Intuwrap should be placed around the plastic pipe and secured using the built in self-adhesive tab, with the lower edge of the Intuwrap level with the soffit of the floor. It is essential that there is no gap between the surrounding constructions. Any gaps should be grouted using the Quelfire QF2 Fire Protection Compound.

