

Fixing Instructions

Caution! - Product has sharp edges! Wear gloves when handling.

Quelfire QRS CE Marked Intumescent Fire Sleeves are life saving products designed to prevent the spread of fire where plastic pipes or plastic ducts penetrate fire compartment walls. It is therefore essential that they are fitted in a responsible and workmanlike manner.

The Quelfire QRS Intumescent Fire Sleeve should be placed around the ventilation duct, positioned centrally within the partition and should be flush or protrude from each face of the wall. The plasterboard should be cut to a tight fit around the Quelfire QRS Intumescent Fire Sleeve and any gaps should be sealed with Quelfire GM Intumescent Acoustic Sealant.

To make installation easier, there is a sticky tab on each flat duct QRS unit that can be used to secure the sleeve around the pipe/duct. On the Circular QRS units there is a small screw that holds the unit closed. This should be taken out when retrofitting the unit around the pipe/duct and can be put back in once around the pipe/duct.

